



6P27
INSTRUCTION MANUAL

Day setting:


to rotate the hour and minute hands clockwise.

Note :The day is changed during the period from about 0:00 AM to about 5:30 AM.

Normal position,
watch runs

Time setting:

Set to the correct time. Push crown back to position I.



24-HOUR SUB-DIAL SETTING:

The 24-hour hand moves correspondingly with the hour and minute hands. When setting the time be sure to check that the 24-hour hand is set properly.